



- NOTES:
1. WARNING: FOLLOW ADI'S INSTALLATION INSTRUCTIONS. THREE ALTERNATE LOCATIONS ARE SHOWN. EXERCISE CAUTION IN LOCATING THE INDICATOR RELATIVE TO STUDS AND EXISTING OR NEW ELECTRICAL AND PLUMBING SERVICES IN THE WALL.
  3. IF INSTALLING THE INDICATOR IN A NEW POURED CONCRETE WALL OR A NEW CMU BLOCK WALL THAT WILL BE FILLED WITH MORTAR AROUND THE DOOR AND USED AS A BOND-BEAM, ADI STRONGLY SUGGESTS USING A 2.5" INSIDE DIAMETER EMT HORIZONTAL SLEEVE. SEE ADI'S CONCRETE WALL DETAIL & BE SURE TO ORDER ADI'S 6" DIAMETER ESCUTCHEON PLATES FOR CMU OR POURED CONCRETE WALLS.

DWG: Detail-Suggested Locations.dwg

SUGGESTED LOCATIONS FOR AIRFLOW DIRECTION INDICATOR	NTS
---	-----